

STEC INDUSTRIAL SOLUTIONS INC.

TMF Series 12-60 zones

Hot Runner Temperature
Controller Operation Manual



Table of contents

- | | |
|-----|--|
| 1 | Specification/function/alarm description |
| 2 | Operation interface |
| 3/4 | Operation instructions |
| 5 | Maintenance |
| 6 | Statement of responsibility |

We focus on hot-runner temperature controller
Provide world-class temperature control solution for hot runner mold

1-844-310-STEC (7832)
www.StecOnline.com

Specification

- Control error : $\pm 2^{\circ}\text{F}$ ($\pm 1^{\circ}\text{C}$)
- Cold junction compensation error : $\leq \pm 2^{\circ}\text{F}$ ($\leq \pm 1^{\circ}\text{C}$) temperature coefficient
- Scope of temperature control : $0-752^{\circ}\text{F}$ ($0-400^{\circ}\text{C}$) for K-type thermocouple; $0-752^{\circ}\text{F}$ ($0-400^{\circ}\text{C}$) for J-type thermocouple
- Total output power: : 50KW
- Maximum output current of single circuit: 15A
- Alarm scope: freely set within $0-200^{\circ}\text{F}$ ($0-100^{\circ}\text{C}$)
- Applicable model of thermocouple: K and J
- Working power supply: AC240V (three-phase)
- Digital PID adjustment
- Working environment: -10°C - 60°C , relative humidity of 35%-85%RH. Non-corrosive and no strong electromagnetic radiation

Function

- Large-screen visual display of LCD graph
- Touch key-press control
- Display of current and output proportion
- Prompt of fuse damage
- Malfunction detection on thermocouple
- Malfunction detection on heating tube
- SCR temperature detecting
- SCR temperature detecting
- Maximum current limiting function
- The linear voltage is adopted to control the output so as to provide better protection for heating tube

Alarm description

- Acoustic alarm:
Acoustic alarm: interrupted alarm sound—communication fault
Continuous alarm sound—control alarm
- Prompt symbol of alarm:

Over	voltage
Low	temperature
Communication	fault
Fuse	damage
Heating	open-circuit
Heating	short-circuit
SCR	high temperature
SCR	open-circuit
SCR	short-circuit
TC	Reverse
Over	temperature
TC	open

- Status symbol:
OFF RUN FLW DIS MT

Note: Please turn off the main power on backboard if you don't use this machine for a long time !

Operation interface

■ The main display interface



■ Setting temperature interface



■ Single-circuit parameter setting interface



Operation instructions

■ 1.Startup & shutdown:

①.Move the power main switch on backboard of control cabinet to the position ON .

As shown in figure



③.If it is required to set single-circuit switch, press down the display frame of this circuit "ON/OFF" key on upper left corner

As shown in figure



②.Press down "Open/Close" button on main display interface of screen.

As shown in figure






■ 2.Temperature setting:

Press down "SV" key, and then the keyboard setting interface will appear on the screen press down the required temperature, and then press down "enter" key.

As shown in figure



If it is required to set the whole circuit as same temperature, for example, set the first 10 circuits as same temperature, you only need to press down "COPY" key  on upper right corner after setting the temperature of circuit 1, and then the  below the screen will show the selected circuit number 1; then, you need to press down "COPY" key  of circuit 2-9 and then you can quickly set circuit 2-9 to have a same temperature with circuit 1.

■ 3.Parameter setting:

If you need to adjust the parameter of this control circuit, enter into temperature setting interface and press down "parameter" key.






After you enter into parameter setting interface,



move the cursor.

1.手动设置/Auto/Manual set

after you move the cursor to the parameter to be set, press left and right key  

to select setting parameter, or directly type in parameter on keyboard. After completion of setting, press down "enter" key. 

If you need to recover this circuit to factory settings, it is ok to press down "reset" key.




- ① Auto/Manual set:
 - Set range : Auto and Manual.
 - For automatic set-up, controller will automatically control temperature in accordance with thermocouple signals; for manual setup, controller will output the percentage "parameter 2" .
- ② Manual output:
 - Set range : 0-100% it is required to set the parameter 1 as manual
 - For manual mode, set the percentage output
- ③ Thermocouple type
 - Set range : J or K
- ④ Alarm function :
 - Set range : Enable or Disable
 - For setting at "Disable" , controller will not alarm in case of abnormal situations.
- ⑤ Over temperature range :
 - Set range : 0-200°F
 - For set temperature of 30°F, the system will alarm when actual temperature exceeds the set temperature of +30°F.
- ⑥ Low temperature range:
 - Set range : 0-200°F
 - For set temperature of 30°F, the system will alarm when actual temperature is below the set temperature of -30°F.
- ⑦ Temperature correction range:
 - Set range : -15°C15°C
 - This parameter unit is Celsius degree.
- ⑧ Control mode:
 - Set range : zero_cr or PWM
- ⑨ SCR alarm :
 - If there is SCR fault parameter, it will display short circuit or open circuit. It is empty Under normal conditions.
- ⑩ Soft start time:
 - Set range: 1-99min.
- ⑪ Soft start output :
 - Set range : 0-100%
- ⑫ PID control parameter P:
 - Set range : 0-999
- ⑬ PID control parameter I:
 - Set range : 0-999
- ⑭ PID control parameter D:
 - Set range : 0-999
- ⑮ Maximum current note:
 - Maximum current note is used for recording the maximum current of controller.
- ⑯ Maximum work current limit :
 - Maximum work current limit is used for displaying the maximum output current of controller. For setting of 12.0, the maximum output current of controller is 12A.
- ⑰ Delay start time:
 - Set range : 0-99min.
 - For setting at 0, the controller will start without delay. After opening the switch, the controller will be at temperature-control mode. If the time is set at 20min, after opening the switching, the controller will not enter in temperature-control mode immediately until 20min later.
- ⑱ Follow control:
 - Set range : 0-60
 - For setting at Disable, the controller is in normal temperature-control mode. For setting at 1, the controller will enter tracking output model. The output voltage of controller will be the same with the output voltage of Channel 1.
- ⑲ Load testing:
 - Set range: 5-12
 - Set the sense resistor of heater, the smaller of the number, the smaller of the allowed heater resistance.


Maintenance

■ Replacement of control card

If it is found that there is any damage in control card in the use process, you can pull out the control card and replace it of standby control card. Before the standby control card is inserted, it is required to set address code of control card; see figure below as for address setting:



■ Description on indicator light of control card



Warning!

- 1.The main power on backboard must be closed before you replace die and pull out connecting cable !
- 2.The main power on backboard must be closed before you replace or maintain control card uni !
- 3.Please close battery main switch if you don't use this product for a long time !
- 4.The control cabinet must have reliable earthing before it is used !
- 5.Please confirm the arrangement mode of heater and thermocouple of control cabinet and die before connection of die .

This product is of metal shell; there shall be good earthing while it is used so as to avoid electric shock! !

Statement of responsibility

- Although we have designed many design measures in the control cabinet, the user still shall set suitable protective device in application system of control cabinet. In full consideration of loss which may be caused due to reliability of controller, we state that we will not bear responsibility of compensation for all losses (including personal or property, etc.) caused due to reliability of controller or other reasons except the control cabinet itself.

Technical department:

- Email: Yogen@StecOnline.com

Sales consulting:

- Email: Yoven@StecOnline.com

Website: www.StecOnline.com



Toll-Free: 1-844-310-STEC (7832)

